

The needed finesse for most of these installations – Is to have the edge of the post in alignment with the roadway – to ensure that the sign face is towards the on-coming traffic.

A Wood Post-attach with wood screws or **Metal Post with holes** – The address sign can be drilled and bolted. This is the most cost effective...



Wood Post Alternatives

Y3518 \$11 <https://www.safetysign.com/products/13750/wall-or-post-wing-bracket?s=st1zskd9nszgp1sxjzbp1cm>

Y3514 \$20 <https://www.safetysign.com/products/13749/wood-post-sign-bracket?s=st1zskd9nlzgp1sxhzbp1cm>



Wall or Post Wing Bracket – Flag Style

Use to mount 911 address signs

Item Y3518



Item #: Y3514-4W4F

Metal Post Alternatives

- Y3445 <https://www.safetysign.com/products/13754/90-degree-u-channel-post-sign-bracket?s=st1zsk1r88zgp1sxwzbp1cm>
- Y3443 <https://www.safetysign.com/products/13753/180-degree-u-channel-post-sign-bracket?s=st1zsk1r87zgp1sxvzbp1cm>
- Y3506 <https://www.safetysign.com/products/13755/adjustable-angle-u-channel-post-sign-bracket?s=st1zskd9n2zgp1sxxzbp1cm>



Item #: Y3445



Item #: Y3443



Item #: Y3506-AU5F